

Quick Start Guide

INSTEON® OutletLinc™ On/Off Outlet Model: 2473S


Tools Needed

- Flathead screwdriver
- Phillips screwdriver
- Wire cutter/stripper
- Voltage tester

Installing OutletLinc

Installation should only be performed by a qualified electrician or a homeowner who is familiar and comfortable with electrical circuitry. If you have questions, consult an electrician or call the INSTEON Support Line at 866-243-8022

- 1) At the circuit breaker or fuse panel, disable circuit supplying power to outlet
- 2) Remove existing outlet and wallplate
- 3) Disconnect wires from existing outlet and ensure you have ½" of bare wire on the ends
- 4) Enable power to the outlet, then use voltage meter to identify line, neutral and ground wires. Once wires are identified, turn off circuit breaker.
- 5) Twist OutletLinc ground wire (bare copper) to outlet ground wire with included wire nut
- 6) Twist OutletLinc neutral wire (white) to outlet neutral wire with included wire nut
- 7) Twist OutletLinc line wire (black) to outlet line wire with included wire nut
- 8) After ensuring all wire connectors are firmly attached and that there is no exposed copper (except for ground wire), carefully place OutletLinc into wall box and replace wallplate
- 9) Turn on circuit breaker
- 10) Plug lamp, appliance or other device you want to control (load) into OutletLinc top outlet
- 11) Test by tapping OutletLinc Set button a few times
Connected light/load will turn on and off



Make OutletLinc a Responder

Control OutletLinc from another INSTEON device:

- 1) Put controller into linking mode.* (For most controllers press and hold Set button for 3 seconds or an on/scene button for 10 seconds.)
- 2) Turn on load plugged into OutletLinc
- 3) Press and hold OutletLinc Set button for 3 seconds
Status LED will flash, then turn on solid
- 4) Confirm link by tapping controller's button on and off
Connected light/load will turn on and off

Owner's Manual and Tech Support

For the complete Owner's Manual and the most up-to-date Quick Start Guide visit: <http://www.insteon.com/support>
Call: INSTEON Support Line at 866-243-8022

*Linking mode will time out after 30 seconds